

RUP Dicamba Application Record 2021-2025

(This form is an example developed by NDA. No specific format is required as long as the information below is recorded)

Complete **both** pages of this template for each application of Engenia, XtendiMax or Tavium

Prior to Application

Applicator Name: _____ NE Applicator ID: NEB _____
Name of Customer: _____

___: Purchase receipts for both dicamba product and pH buffering agent
___: Copy of Product Label
___: Completed Auxin-specific training- Date: _____ Location: _____ Provider: _____
___: Sensitive Crop Awareness: Dates-FieldWatch: _____
___: Crop Survey Date and Person Doing Survey: _____
___: Endangered Species Protection Bulletin, Date Bulletin Printed: _____

Application Details

Location of Application: _____
RUP Dicamba Product Name: _____ EPA Reg. Number: _____
Date of Application (M/D/Y): _____ Crop Treated: _____ Size of Treated Area: _____
Total Amount of RUP Dicamba Product Applied: _____
Nozzle Used (Company and model #): _____
Pressure at the Nozzles: _____ (PSI) _____ Pre or _____ Post-emergence application

Buffer Requirements/Calculations (see page 2 for space to sketch a map):

Tank Mix Partners-Products (including pH buffer)	EPA Registration Number	Rate of Application

Spray Conditions (at boom height using wind meter, not phone app)

Start:
Time: _____ Wind Speed/Direction: _____ Air Temp: _____
Finish:
Time: _____ Wind Speed/Direction: _____ Air Temp: _____

Comments on any changes of wind direction during application:

Spray System Cleanout (see top of next page):
_____ Pre-application cleanout completed; _____ Post-application cleanout completed

Spray System Cleanout

BEFORE	AFTER	
---------------	--------------	--

- | | | |
|-------|-------|--|
| <hr/> | <hr/> | 1. After spraying, drain the sprayer (including boom and lines). Avoid allowing the spray solution to remain in the spray boom lines overnight or for extended periods of time. |
| <hr/> | <hr/> | 2. Flush tank, hoses, boom, and nozzles with clean water. Open boom ends and flush if so equipped. |
| <hr/> | <hr/> | 3. Inspect and clean all strainers, screens, and filters. |
| <hr/> | <hr/> | 4. Use commercial sprayer cleaner containing strong detergents according to the manufacturer's directions. |
| <hr/> | <hr/> | 5. Wash all parts of the tank, including the inside top surface. Start agitation in the sprayer and thoroughly recirculate the cleaning solution for at least 15 minutes. All visible deposits must be removed from the spraying system. |
| <hr/> | <hr/> | 6. Flush hoses, spray lines, and nozzles with the cleaning solution for at least 1 minute. Remove nozzles, screens, and strainers, and clean separately in the cleaning solution after completing the above procedure. |
| <hr/> | <hr/> | 7. Drain pump, filter, and lines. Repeat steps 2 and 3. |
| <hr/> | <hr/> | 8. Rinse the complete spraying system with clean water. |
| <hr/> | <hr/> | 9. Clean and rinse the exterior of the sprayer. |
| <hr/> | <hr/> | 10. Appropriately dispose of all rinsate in compliance with local, state, and federal requirements (at target site or if over loadout pad, collect rinsate in dedicated tank) |

Space provided for map or buffer calculation